

20.02. Configure VVM for a Mobile store


There are a few configuration steps needed in mSupply desktop for setting up the Vaccine module to be used in mSupply mobile. This page is all about those steps.

To set up the vaccine module correctly, you need to:

- Enable the vaccine module for the mobile store
- Set up sensors, and
- Set up temperature breach configurations

Enable the vaccine module for the mobile store

First of all, in mSupply desktop login to the store you want to turn on the vaccine module for. Then, from the menus, choose *Special > Show Stores*, double-click on the store you are logged into and then click on the *Preferences* tab. This is the window you will see:



Check the **mobile: Uses Vaccine module** checkbox in the *Store preference* list and click on the **OK** button to save the new setting.


Viewing sensor details

Temperature sensors are used by mSupply mobile to monitor the temperature over time at a given location. This section describes the options available within mSupply to view/interact with temperature sensors.

First of all, you need to have permission in the system to view sensor details. See the [23.15. Managing users](#) page for details on how to set user permissions. You need to turn on the *View sensor details* permission on the *Permissions (3)* tab.

To see the current sensors go to *Item > Vaccines > Sensors...*

This window will appear:



The window will show you a list of all the current sensors that have been set up. If there are many in the list, you can type something in the search bar and only those containing what you types will show in the list. To view the details of one, simply double-click on it in the list. This will open a window populated with the sensor's current settings.

You cannot add a sensor or edit any of the sensor details. This can only be done in mSupply mobile (see the [Cold Chain \(for Vaccines and other Cold chain items\) - mobile](#) page for details).

Viewing temperature breach configurations

Temperature breaches occur when the temperature detected by a temperature sensor exceeds a certain value for a certain amount of time. This section describes how temperature breaches are defined in mSupply.


First of all, you need to have permission in the system to configure temperature breaches.

See the [23.15. Managing users](#) page for details on how to set user permissions. You need to turn on

the *View temperature breach configuration* permission on the *Permissions (3)* tab.

To see the current temperature breaches go to *Item > Vaccines > Show temperature breach configuration...*

This window will appear:




The window will show you a list of all the current temperature breach configurations that have been set up. If there are many in the list, you can type something in the search bar and only those containing what you types will show in the list. To view the details of one, simply double-click on it in the list. This will open a window (see below) populated with the breach's current settings.

You cannot add, edit or delete a temperature breach configuration, this can only be done in mSupply mobile (see the [Cold Chain \(for Vaccines and other Cold chain items\) - mobile](#) page for details).

To view the details of a temperature breach configuration

When you double-click a temperature breach configuration, this window will open, pre-populated with the configuration's details:



A screenshot of a 'Temperature breach configuration' dialog box. It has a title bar with red, yellow, and green window control buttons. The dialog contains the following fields: 'Description' (empty), 'Minimum Temperature' (10 Celsius), 'Maximum Temperature' (999 Celsius), 'Duration' (0 hour 20 minutes), 'Type' (Hot consecutive), 'Location type' (None), and 'Is active?' (unchecked checkbox). At the bottom is a blue 'OK' button.

Description	
Minimum Temperature	10 Celsius
Maximum Temperature	999 Celsius
Duration	0 hour 20 minutes
Type	Hot consecutive
Location type	None
Is active?	<input type="checkbox"/>
OK	

- **Description:** The name given to the configuration. It will be referred to by this throughout mSupply.
- **Minimum temperature:** If the temperature drops below this, it will contribute towards a breach
- **Maximum temperature:** If the temperature rises above this, it will contribute towards a breach
- **Duration hours and minutes:** The length of time the temperature must be below the minimum or above the maximum temperatures for a cumulative breach to occur.
- **Type:** The breach configuration type, see [Cold Chain \(for Vaccines and other Cold chain items\) - mobile](#) for details on the breach types available.
- **Location type:** The location type this breach belongs to. See the [4.06. Stock locations and location types](#) page for details on location types.
- **Is active?:** If checked then this breach configuration will be used in cold chain monitoring. If unchecked, it won't.

Click on the **OK** button to close the window.

Previous: [20. Cold Chain Equipment](#) | | Next: [20.03. Cold Chain App Notifications](#)

From:
<https://docs.msupply.org.nz/> - mSupply documentation wiki

Permanent link:
https://docs.msupply.org.nz/cold_chain_equipment:mobile?rev=1670480069

Last update: **2022/12/08 06:14**

